





Use screens better



Airtame 2 is a device for streaming content wirelessly. Plug it into the HDMI port on your TV or projector and share your screen from any device. Say goodbye to cables.



Mirror your screen from any device

You no longer have to juggle different types of input cables – Airtame 2 connects wirelessly to any device running on any platform. You can even connect your mobile devices. Use Airplay to connect your iPhone or iPad, and our app to show images and slides from your Android device.


Free customer support. For life

Whether you buy one or 100 Airtame 2s, our Customer Success team are always at hand to help you find flow in your office.

Digital Signage


Blank screens are no fun – make yours stand out. Display KPIs, custom images, Google Slides or websites with Airtame 2.

In the Homescreen section of the Airtame 2 cloud you have a visual overview of all your screens.



Cloud management

Reduce support requests with Airtame 2 Cloud – an IT admin's dream. Easy remote management that lets you manage and monitor devices without leaving your chair.



PIN Code Connect

Keep in control. When enabled, a new code is presented on screen every time you want to connect, meaning that connecting is quick, stable and safe.

System requirements

Minimum Dual core 1.6GHz CPU / 1GB RAM **WiFi:** 802.11g **OS:** Windows 7, Ubuntu 15.04, Mac OS X 10.9, iOS 9, Android 4.2.2

Recommended Computer from 2011 or newer Dual core 2.8GHz CPU 4GB RAM **WiFi:** 802.11 a / n / ac **OS:** Win 10, Ubuntu 15.04, Mac OS X 10.12, iOS 9, Android 4.2.2

Router recommendation 2.4 GHz n or 5 GHz n / ac MIMO 2x2 300 MBit

More info Visit www.Airtame 2.com/ or contact us at support@Airtame 2.com

Supports Windows, Mac OS, Chromebook, Linux, Airplay, Android*



*Using our native app